

ASTORIA, RITZ, IBIS, STRAND, PORTO AND BRAGA BATHROOM WALL LAMPS



INFORMATION AND INSTALLATION

Thank you for choosing this Valsan product. It has been manufactured with care from quality materials and when installed correctly should give many years of trouble free service. To ensure your complete safety and satisfaction, before commencing any installation please ensure that you have read and fully understood the following instructions.

THIS LAMP MUST BE INSTALLED BY A QUALIFIED LICENSED ELECTRICIAN.

It is recommended that a qualified licensed electrician read the following before beginning installation.

WARNING: Shut off electricity supply by either removing the fuse or switching the circuit breaker off before and during installation and maintenance. We recommend that the circuit fuse is withdrawn to prevent accidental switching on while work is in progress.

1. Unscrew the shade(s) from the lamp if required. Please note that the glass shade and the chrome ring are integrated. Unscrew the entire shade at the point just below the bottom ring.
2. To remove the mounting crossbar from the back of the lamp, first unscrew the setscrew securing it in the top of the lamp arm where it enters the wall plate using the allen wrench provided. Pull the crossbar and cover plate* carefully away from the lamp while taking care not to place undue strain on the wires to the lamp.
*(if applicable to lamp style)
3. Mount crossbar to the wall outlet box using 2 outlet box screws with the spindle facing away from the wall. Attach the green ground wire to a suitable grounding position after attaching the crossbar to the outlet box.
4. Feed the lamp wires through the cover plate (where applicable) and the center hole in the crossbar.
5. Carefully support the lamp while making the following connections:
Connect the white (neutral) wire of the lamp to the white (neutral) wire of the wall supply using a wire nut.
Connect the black (hot) wire of the lamp to the black (hot) wire of the wall supply using a wire nut.
6. Feed the wires from the lamp through the spindle of the crossbar, as you bring the lamp toward it, locating the spindle through the cover plate (where applicable) and into the hole in the back of the lamp ensuring that no wires are trapped or pinched during the process.
7. Bring the lamp flush to the wall box and tighten the setscrew in the top of the lamp arm using the allen wrench.
8. Finally screw the shade(s) back on to the lamp.

IMPORTANT

This lamp is for indoor use only.

WATTAGE

This lamp should be fitted with a candelabra base – 60 watt - torpedo shape, bulb.

Never exceed the maximum wattage as indicated on the socket.

60 watt is recommended even though the socket is rated at 75 watts.

CARE OF THIS PRODUCT

Clean only with a dry soft cloth.

Do not use any proprietary cleaners and polishes which may have a detrimental effect on the finish.